

# Фрезы универсальные со сферическим торцом

## Конический хвостовик





Схема	Обозначение	D	l	L	KM	z
	С крупным зубом					
	CK 526-8-19-89-KM1	8	19	89	1	2
	CK 526-10-22-92-KM1	10	22	92	1	2
	CK 526-12-26-96-KM1	12	26	96	1	2
	CK 526-14-26-111-KM2	14	26	111	2	2
	CK 526-16-32-117-KM2	16	32	117	2	2
	CK 526-18-32-117-KM2	18	32	117	2	2
	CK 526-20-38-123-KM2	20	38	123	2	2
	CK 526-22-38-123-KM2	22	38	123	2	2
	CK 526-25-45-147-KM3	25	45	147	3	2
	CK 526-28-45-147-KM3	28	45	147	3	2
	С нормальным зубом					
	CK 527-8-19-89-KM1	8	19	89	1	4
	CK 527-10-22-92-KM1	10	22	92	1	4
	CK 527-12-26-96-KM1	12	26	96	1	4
	CK 527-14-26-111-KM2	14	26	111	2	4
	CK 527-16-32-117-KM2	16	32	117	2	4
	CK 527-18-32-117-KM2	18	32	117	2	4
	CK 527-20-38-123-KM2	20	38	123	2	4
	CK 527-22-38-123-KM2	22	38	123	2	4
CK 527-25-45-147-KM3	25	45	147	3	4	
CK 527-28-45-147-KM3	28	45	147	3	4	
Группа применения						
P	M	K	N	S	H	
<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
ТУ 25.73.40-032-36293294-2019						