

# Фрезы чистовые

Цилиндрический хвостовик






Схема	Обозначение	D	l	L	d	z
	Короткая серия					
	Ч 631-3-6-39-C3	3	6	39	3	5
	Ч 631-4-8-51-C4	4	8	51	4	6
	Ч 631-5-9-51-C5	5	9	51	5	6
	Ч 631-6-10-51-C6	6	10	51	6	6
	Ч 631-8-12-59-C8	8	12	59	8	6
	Ч 631-10-14-67-C10	10	14	67	10	6
	Ч 631-12-16-74-C12	12	16	74	12	6
	Ч 631-14-18-76-C14	14	18	76	14	6
	Ч 631-16-22-83-C16	16	22	83	16	6
	Ч 631-18-24-85-C18	18	24	85	18	8
	Ч 631-20-26-93-C20	20	26	93	20	8
	Средняя серия					
	Ч 632-3-12-39-C3	3	12	39	3	5
	Ч 632-4-12-51-C4	4	12	51	4	6
	Ч 632-5-15-51-C5	5	15	51	5	6
	Ч 632-6-15-58-C6	6	15	58	6	6
	Ч 632-8-20-64-C8	8	20	64	8	6
	Ч 632-10-22-73-C10	10	22	73	10	6
	Ч 632-12-26-84-C12	12	26	84	12	6
	Ч 632-14-26-84-C14	14	26	84	14	6
Ч 632-16-33-93-C16	16	33	93	16	6	
Ч 632-18-33-93-C18	18	33	93	18	8	
Ч 632-20-42-105-C20	20	42	105	20	8	

Схема	Обозначение	D	l	L	d	z
	Длинная серия					
	Ч 633-6-30-80-C6	6	30	80	6	6
	Ч 633-8-45-89-C8	8	45	89	8	6
	Ч 633-10-45-89-C10	10	45	89	10	6
	Ч 633-12-45-100-C12	12	45	100	12	6
	Ч 633-14-45-100-C14	14	45	100	14	6
	Ч 633-16-45-110-C16	16	45	110	16	6
	Ч 633-18-60-130-C18	18	60	130	18	8
Ч 633-20-60-150-C20	20	60	150	20	8	
Группа применения						
P	M	K	N	S	H	
<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
ТУ 25.73.40-059-36293294-2019						